Laxihub

QUICK GUIDE
M2/M2C

EN Smart Indoor Wi-Fi Camera

DE Smarte WLAN IP-Kamera für Innen

FR Caméra intelligente Wi-Fi intérieure

ES Cámara inteligente Wi-Fi para interiores

IT Telecamera Wi-Fi Smart per interni

RU Умная внутрення Wi-Fi видеокамера

NL Slimme Wi-Fi Camera voor binnen

What's in the box

Please consult this checklist for all parts.

M2/M2C	Power adapter
USB cable	Adhesive pad
User manual	Pin

Microphone
Status light
SD card slot
Reset
Power port

Description

| Power	DC5V±10%
Status light	• Red light solid on: the camera network is abnormal • Blinking red light: awaiting WiFi connection; or currently connecting (faster blinking) • Blue light solid on: camera working correctly • Blinking blue light: currently reconnecting (faster blinking)
Microphone	Capture sounds for your video

SD card slot	Support local SD Card storage (Max.128GB)
Reset	Press and hold for 5 seconds with pin to reset the device (if you have modified settings, then they will return to factory defaults)

Install

1 Stick the adhesive pad in the middle of camera bottom

2 Put the camera on the clean plane

Set-up

• Plug in

Plug the camera into an outlet. An audible sound will play when the system is ready for operation.

• Adding

Download our Smart Life App by scanning the following QR codes or searching in your app store. Follow the prompts on the App to finish setup.


your network

**SUPPORT**

iPad

iOS

Android

Download App
(iOS & Android)

• Registration

Step 1 Open the Smart Life App, click "Sign Up", and select the country or region where your account is located. Input a legal and valid phone number or email address and then click "Get Verification Code".

Register

United States of America

id@email.com

Get Verification Code

I Agree User Agreement and Privacy Policy

Step 2 Input Verification Code and create a password which is required a combination of numbers and letters, not less than 6 digits. Then click "Log In".

Enter Verification Code

_ _ _ _ _ _

A verification code has been sent to your email
id@email.com Resend (59s)

Didn't get a code?

Log In

United States of America >

Please enter your account

Password

Log In

Forgot Password

Note: Make sure your router, camera, and
mobile phone are nearby.

QR Code Configuration

• Few notice before adding the device

1. This camera only supports 2.4GHz WiFi network, so please make sure you are using a wireless router that supports 2.4GHz band.

2. Please follow the instructions and make sure the password is inputted correctly.

• Process

Step 1 Open the Smart Life App, click "+", and select "Video Surveillance".

Step 2 Please confirm the indicator rapidly blinks. Click "QR Code", then click "Next".

Step 3 Input WiFi password, click "Next", and scan the QR Code with this camera.

About 20cm

Step 4 Click "I Heard a Prompt" when the device plays a tone "dong dong dong". And you can complete the configuration in about 30s.

FAQ

Q: During the network configuration process, if the progress bar is always not 100%, meaning the adding failed?

A: This camera only supports 2.4GHz WiFi network, please make sure you are using a wireless router that supports 2.4GHz band.

Q: What to do when the live video cannot be viewed properly?

A: Check whether the network is normal, you can place the camera close to the router, and if not, it is recommended to reset the device and add it again.

Q: Why is it still in the list of devices after resetting?

A: The resetting function will only reset the network configuration of the camera, while other settings including the camera info. will remain on the App. To remove the camera, please delete it from the device list on the App.

Q: How to switch the camera network to another router?

A: First remove the device on the App and/or reset it and then add the device again.

Q: Why doesn't the device identify the SD card?

A: It is recommended to insert the SD card while keep the power off. Confirm whether the SD card is normally workable and its format is FAT32. And the SD card cannot be identified when network is not in good conditions.

Q: Why I can't get the notifications with my cell phone app?

A: Please confirm that the App has been running on your cell phone after registration, and the reminder functions have been enabled on the App, also make sure notifications and the relevant authorities in your cell phone system have been enabled.

Functions

• Video flip
Flip your video stream vertically anytime for maximum flexibility.

• Motion detection
Motion detection will notify you when movement is detected.

• Record
Record every moment using high capacity SD card storage.

• Day & Night
Powerful night vision means no interruptions, even in complete darkness.

Daytime

Night