laxihub



EN Smart Indoor Wi-Fi Camera

- DE Smarte WLAN IP-Kamera für Innen
- FR Caméra intelligente Wi-Fi intérieure
- ES Cámara inteligente Wi-Fi para interiores
- IT Telecamera Wi-Fi Smart per interni
- RU Умная внутренняя Wi-Fi видеокамера
- NL Slimme Wi-Fi Camera voor binnen



CONTENT

English	.01
Deutsch	12
Français	. 23
Español	
Italiano	. 45
Русский	56
Dutch	. 67

What's in the box

Please consult this checklist for all parts.





_	
Descr	Infion
00001	

Power	DC5V±10%
Status light	 Red light solid on: the camera network is abnormal Blinking red light: awaiting WiFi connection; or currently connecting (faster blinking) Blue light solid on: camera working correctly Blinking blue light: currently reconnecting (faster blinking)
Microphone	Captures sounds for your video

SD card slot	Supports local SD Card storage (Max.128GB)
Reset	Press and hold for 5 seconds with pin to reset the device (if you have modified settings, then they will return to factory defaults)

Install

1 Stick the adhesive pad in the middle of camera bottom



English

2 Put the camera on the clean plane





• Plug in

Plug the camera into an outlet. An audible sound will play when the system is ready for operation.



(iOS & Android)

Adding

Download our Smart Life App by scanning the following QR codes or searching in your app store. Follow the prompts on the App to finish setup.



Registration

Step 1 Open the Smart Life App, click "Sign Up", and select the country or region where your account is located. Input a legal and valid phone number or email address and then click "Get Verification Code".



Registe		
United State	es of America	
idpenal.co	m	
(•	et Verification Code	
E (Apre)	Line: Aerosensent and Pri	acc. Palicy

English

Step 2 Input Verification Code and create a password which is required a combination of numbers and letters, not less than 6 digits. Then click "Log In".

Enter Verification Code	Log In
	United States of America
	Please enter your account
	Password
A verification code has been sent to your email id@email.com Resend (59s)	
Didn't get a code?	
	Forgot Password

Note: Make sure your router, camera, and mobile phone are nearby.

QR Code Configuration

· Few notices before adding the device

1. This camera only supports 2.4GHz WiFi network, so please make sure you are using a wireless router that supports 2.4GHz band.

2. Please follow the instructions and make sure the password is inputted correctly.

Process

Step 1 Open the Smart Life App, click "+", and select "Video Surveillance".



Step 2 Please confirm the indicator rapidly blinks. Click "QR Code", then click "Next".



Step 3 Input WiFi password, click "Next", and scan the QR Code with this camera.

English

U U	About 20cm
2.4снг 25снг	
🔶 Market 😑	
A Password	E 2
Next	

Step 4 Click "I Heard a Prompt" when the device plays a tone "dong dong dong". And you can complete the configuration in about 30s.





FAQ

Q: During the network configuration process, if the progress bar is always not 100%, meaning the adding failed?

A: This camera only supports 2.4GHz WiFi network, please make sure you are using a wireless router that supports 2.4GHz band.

Q: What to do when the live video cannot be viewed properly?

A: Check whether the network is normal, you can place the camera close to the router, and if not, it is recommended to reset the device and add it again.

Q: Why is it still in the list of devices after resetting?

A: The resetting function will only reset the network configuration of the camera, while other settings including the camera info. will remain on the App. To remove the camera, please delete it from the device list on the App. Q: How to switch the camera network to another router?

A: First remove the device on the App and/or reset it and then add the device again.

Q: Why doesn't the device identify the SD card?

A: It is recommended to insert the SD card while keep the power off. Confirm whether the SD card is normally workable and its format is FAT32. And the SD card cannot be identified when network is not in good conditions.

Q: Why I can't get the notifications with my cell phone app?

A: Please confirm that the App has been running on your cell phone after registration, and the reminder functions have been enabled on the App, also make sure notifications and the relevant authorities in your cell phone system have been enabled.

Functions

• Video flip

Flip your video stream vertically anytime for maximum flexibility.

- Motion detection
 Motion detection will notify you when movement is
 detected
- Record

Record every moment using high capacity SD card storage.

• Day & Night

Powerful night vision means no interruptions, even in complete darkness.



Daytime



Night